Canon

LC-100T
INSTRUCTIONS /
INSTRUKSI

ENGLISH
BAHASA INDONESIA

ENGLISH

■ Before using this product, please read this manual carefully. Please keep it for future reference.

POWER SUPPLY

This calculator comes with alkaline battery power source. The duration of the battery depends on individual usage.

(**NOTE:** Do not attempt to change the battery by yourself. Visit a Canon Service Center to change the battery for you).

⚠ Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the contents of the memory to be lost or altered. If this occur, press the 🔄 key and restart your calculation from the beginning.

TAX FUNCTION

🔄 SET **Store the tax rate:** Press 🔄 SET and enter the tax rate, then press SET to store.

🔄 RECALL **Recall the tax rate:** Press 🔄 RECALL to recall the stored tax rate.

TAX+ **Add tax key:** Used for adding the tax amount to the display figure.

TAX− **Deduct tax key:** Used for deducting the tax amount from the displayed figure.

OVERFLOW FUNCTIONS

In the following cases, error message (E) will be shown on the display. The keyboard is electronically locked, and further operation is impossible. Press CI/C key to clear the overflow. The overflow occurs when:
1. The result or the memory contents exceeds 10 digits to the left of the decimal point.
2. Dividing by "0".

SPECIFICATION

Power Source: Alkaline battery (LR44 x 1)
Operating Temperature: 0°C to 40°C
Auto-power off: approx. 7 minutes
Dimension: 118.5mm (L) x 83mm (W) x 22mm (H)
Weight : 73g
(Subject to change without notice)

BAHASA INDONESIA

■ Sebelum menggunakan produk ini, silahkan baca petunjuk ini dengan seksama. Mohon disimpan untuk referensi.

CATU DAYA

Kalkulator ini dilengkapi dengan sumber daya baterai alkali. Umur baterai hanya tergantung pada penggunaan masing-masing.

(**CATATAN:** Jangan mencoba mengganti baterai sendiri. Mintalah bantuan Canon Service Center untuk mengganti baterai untuk Anda).

⚠ Gangguan elektromagnetik atau lucutan elektrostatik dapat menyebab kan kerusakan pada tampilan atau isi di dalam memori hilang atau berubah. Apabila yang demikian ini terjadi, tekan tombol 🔄 dan ulangi kalkulasi Anda dari awal.

FUNGSI KALKULASI PAJAK

🔄 SET **Menyimpan Tarif Pajak:** Tekan 🔄 SET dan masukkan angka tarif pajak, kemudian tekan SET untuk menyimpan.

🔄 RECALL **Memanggil Kembali Tarif Pajak:** Tekan 🔄 RECALL untuk memanggil kembali tarif pajak saat ini.

TAX+ **Tombol Add Tax:** Digunakan untuk menambahkan jumlah pajak pada angka yang ditampilkan.

TAX− **Tombol Deduct Tax:** Digunakan untuk memotong jumlah pajak pada angka yang ditampilkan.

FUNGSI OVERFLOW

Pada kasus berikut, pesan kesalahan (E) akan diperlihatkan pada tampilan. Papan ketik terkunci secara elektronik, dan operasi tidak mungkin dapat dilakukan lagi. Tekan CI/C untuk menghapus overflow. Overflow terjadi apabila:
1) Hasil atau isi memori melebihi 10 digit ke sebelah kiri dari titik desimal.
2) Membagi dengan "0".

SPESIFIKASI

Sumber Daya: Baterai alkali (LR44 x 1)
Suhu Operasi: 0°C to 40°C
Catu Daya Mati Otomatis: lebih kurang 7 menit
Dimensi: 118.5mm (L) x 83mm (P) x 22mm (T)
Berat: 73g
(Dapat berubah tanpa pemberitahuan)

⚠ **WARNING / PERINGATAN**

EN Collectible products not intended for children.

IN Produk Koleksi tidak dimaksudkan untuk anak-anak.

CALCULATION / PERHITUNGAN	OPERATION / OPERASI	DISPLAY / TAMPILAN

▼ Mixed / Campuran

	🔲	(0.)
140−35+22=127	140 ➖ 35 ➕ 22 🟰	(127.)
2x 2 /3 =6	2 ✖ 2 ⟐ 3 🟰	(6.)
−7x99 9 =−63	7 ↔ ✖ 99 ➡ 🟰	(−63.)
(2+4)÷3x8.1=16.2	2 ➕ 4 ➗ 3 ✖	
	8 ⬛ 1 🟰	(16.2)

▼ Constant / Konstan

2+3=5	2 ➕ 3 🟰	(5.)
4+3=7	4 🟰	(7.)
1−2=−1	1 ➖ 2 🟰	(−1.)
2−2=0	2 🟰	(0.)
2x3=6	2 ✖ 3 🟰	(6.)
2x4=8	4 🟰	(8.)
6÷3=2	6 ➗ 3 🟰	(2.)
9÷3=3	9 🟰	(3.)

▼ Power, Fraction / Pangkat, Pecahan

3^4 =81	3 ✖ 🟰 🟰 🟰	(81.)
1/5=0.2	5 ➗ 🟰	(0.2)
1/(2x3+4)=0.1	2 ✖ 3 ➕ 4 ➗ 🟰	(0.1)

▼ Square Root / Akar Kuadrat

$\sqrt{3}$ = 1.732050807	3 √	(1.732050807)

▼ Percentage / Persen

200+(200x20%)=240	200 ➕ 20 %±	(240.)
200−(200x20%)=160	200 ➖ 20 %±	(160.)

▼ Memory / Memori

	🔲	(0.)
3x4= 12	3 ✖ 4 M+	(M 12.)
−) 6÷0.2= 30	6 ➗ ⬛ 2 M−	(M 30.)
−18	RM/CM	(M −18.)
+) 200	200 M+	(M 200.)
182	RM/CM (Recall Memory)	(M 182.)
	RM/CM (Clear Memory)	(182.)

CALCULATION / PERHITUNGAN	OPERATION / OPERASI	DISPLAY / TAMPILAN

▼ Grand total / Grand total

30x40= 1,200	30 ✖ 40 🟰	(0.)
50x60= 3,000	50 ✖ 60 🟰	(GT 1'200.)
+) 25x30= 750	25 ✖ 30 🟰	(GT 3'000.)
4,950	GT	(GT 750.)
+) 235x35= 8,225	235 ✖ 35 🟰	(GT 4'950.)
13,175	GT (Recall Grand total memory)	(GT 8'225.)
	GT (Clear Grand total memory)	(GT 13'175.)
		(13'175.)

▼ Tax / Tarif

Tax Rate Set
Tax: 5%

	🔲 SET 5 SET	(TAX% 5.)

Recall Tax Rate

	🔲 RECALL	(TAX% 5.)

Add the Tax Amount
Price $2,000 without tax
Selling price with tax? ($2,100)
Tax amount? = ($100)

	2000	(2'000.)
	TAX+	(TAX+ 2'100.)
	TAX+	(TAX 100.)

Deduct Tax Amount
Selling price $3,150 with tax
Price without tax ? ($3,000)
Tax amount? = ($150)

	3150	(3'150.)
	TAX−	(TAX− 3'000.)
	TAX−	(TAX 150.)

▼ Overflow / Limpah Atas

1) 12345678 x 7890
=97407399420
(Error/Salah)

	12345678 ✖ 7890 🟰	(E 9.740739942)
	CI	(9.740739942)

2) 9999999999 (Add to Memory / Tambahkan ke Memory)
123 (Add to Memory / Tambahkan ke Memory)

	9999999999 M+	(M 9'999'999'999.)
	123 M+	(M/E 1.000000012)
	CI	(M 1.000000012)
	RM/CM RM/CM	(M 9'999'999'999.)

3) 6÷0=0
(Error/Salah)

	6 ➗ 0 🟰	(E 0.)
	CI	(0.)