



WS-2235H

电子计算器 /  
Electronic Calculator



使用说明书 中文  
Instruction EN

## 运算例子 / Calculation Examples

计算举例/ Calculation	按键操作 / Operation	显示/ Display
		123456789012
<b>▼ 混合运算 / Mixed</b>		
140-35+22=127	140 $\ominus$ 35 $\oplus$ 22 $\ominus$	( 127.00)
2 x 2 = 4	2 $\times$ 2 $\ominus$	( 6.00)
-7 x 9 = -63	7 $\ominus$ $\times$ 99 $\ominus$	( -63.00)
<b>▼ 常数运算 / Constant</b>		
2+3=5	2 $\oplus$ 3 $\ominus$	( 5.00)
4+3=7	4 $\oplus$ 3 $\ominus$	( 7.00)
1-2=-1	1 $\ominus$ 2 $\ominus$	( -1.00)
2-2=0	2 $\ominus$ 2 $\ominus$	( 0.00)
2x3=6	2 $\times$ 3 $\ominus$	( 6.00)
2x4=8	4 $\times$ 2 $\ominus$	( 8.00)
6÷3=2	6 $\div$ 3 $\ominus$	( 2.00)
9÷3=3	9 $\div$ 3 $\ominus$	( 3.00)
<b>▼ 功率,份数运算 / Power, Fraction</b>		
34=81	3 $\times$ $\ominus$ $\ominus$ $\ominus$ $\ominus$	( 81.00)
1/5=0.2	1 $\div$ 5 $\ominus$	( 0.20)
1/(2x3+4)=0.1	1 $\div$ ( 2 $\times$ 3 $\oplus$ 4 ) $\ominus$	( 0.10)

计算举例/ Calculation	按键操作 / Operation	显示/ Display
		123456789012
<b>▼ 平方根运算 / Square Root</b>		
$\sqrt{4} = 2$	4 $\sqrt{\quad}$	( 2.)
<b>▼ 附加模式运算 / Add Mode</b>		
\$14.90+\$0.35 = 15.25	1490 $\oplus$ 35 $\ominus$	( 15.25)
<b>▼ 浮动运算 / Floating Calculation</b>		
8÷3x9 = 23.999999999	8 $\div$ 3 $\times$ 9 $\ominus$	( 23.999999999)
<b>▼ 上舍入运算 / Round-up</b>		
28÷3 = 9.34	28 $\div$ 3 $\uparrow$ $\ominus$	( 9.34)
<b>▼ 下舍入运算 / Round-down</b>		
11÷3 = 3.66	11 $\div$ 3 $\downarrow$ $\ominus$	( 3.66)
<b>▼ 凑整运算 / Round-off</b>		
11÷3 = 3.67	11 $\div$ 3 $\updownarrow$ $\ominus$	( 3.67)
<b>▼ 百分比运算 / Percentage</b>		
1200+(1200x 20%)=1,440	1200 $\oplus$ 20 $\% \pm$	( 1'440.00)
1200-(1200x 20%)=960	1200 $\ominus$ 20 $\% \pm$	( 960.00)

计算举例/ Calculation	按键操作 / Operation	显示/ Display
		123456789012
<b>▼ 记忆运算 / Memory</b>		
3x4= 12	3 $\times$ 4 $\text{M}\pm$	(M 12.00)
-) 6÷0.2= 30	6 $\div$ 0.2 $\text{M}\pm$	(M 30.00)
-18	$\text{RM}$ (重呼记忆/ Recall Memory)	(M -18.)
+) 200	200 $\text{M}\pm$	(M 200.00)
182	$\text{RM}$ (清除记忆/ Clear Memory)	(M 182.)
	$\text{CM}$	( 182.)
<b>▼ 总计运算 / Grand Total</b>		
4x30=120	4 $\times$ 30 $\text{GT}$	(GT 120.00)
+) 5x60=300	5 $\times$ 60 $\text{GT}$	(GT 300.00)
420	$\text{GT}$	(GT 420.)
+) 23x35= 805	23 $\times$ 35 $\text{GT}$	(GT 805.00)
1,225	$\text{GT}$ (清除总计/Clear Grand Total)	( 1'225.)
<b>▼ 销售价运算 / Mark-up</b>		
成本/Cost\$2,000		
利润20%/Profit 20% of selling price		
销售价格/Selling price=?( \$2,500)	2000 $\div$ 20 $\text{MU}$	( 2'500.00)
利润/Profit=?( \$500)	$\text{MU}$	( 500.00)
<b>▼ 成本价运算 / Mark-down</b>		
销售价格/Selling price\$2,400		
利润20%/Profit 20% of cost		
成本/Cost=?( \$2,000)	2400 $\div$ 20 $\text{MU}$	( 2'000.00)
利润/Profit=?( \$400)	$\text{MU}$	( 400.00)

计算举例/ Calculation	按键操作 / Operation	显示/ Display
		123456789012
<b>▼ 溢出运算 / Overflow</b>		
1) 123456789 x 78900= 9.740740652100 (溢出/ERROR)→	123456789 $\times$ 78900 $\text{M}\pm$	(E 9.74074065210) ( 9.74074065210)
2) 6÷0= 0 (溢出/ERROR)	6 $\div$ 0 $\text{M}\pm$	(E 0.) ( 0.)

佳能电产香港有限公司  
香港新界葵涌货柜码头路82-100号  
永得利广场第1期17楼

北京通泰嘉怡科技有限责任公司  
北京市西城区北展北街华远企业中心D座  
1单元505室

- 使用本产品前，请务必阅读本使用说明书；保留备用；理解本说明书内容后，请正确使用。

### ⚠ 注意事项

- 切勿在阳光直射下使用计算器。亦应避免把计算器放置于阳光猛烈、潮湿、肮脏(如灰尘)及温度急速变化的地方。
- 使用柔软的干布拭净计算器的外部。切勿使用清水或清洁溶剂。
- 切勿使用坚硬物体或其它尖锐物体按压计算器的按键，避免在机上留下刮痕。
- 切勿扭曲或弯曲或尝试拆开计算器。
- 电力不足可能会使存储器内容损坏或出现故障，请重新开启计算器。

### 供电电源

本计算器配有两种电源：太阳能及锂电池。锂电池的使用时间完全取决于个别的使用情况。

- ⚠ 电磁干扰或静电释放可引起显示故障或存储器的内容丢失或被改变。若出现此情况，请按  $\text{ON/C}$  键重新开始计算。

### 数据溢出功能

在下列情况下，显示幕上将显示出"E" (错误) 字样，键盘也会被锁定，不能继续操作。按  $\text{ON/C}$  键可清除溢出。可导致溢出的情况如下：

- 计算结果或内存数字超过12位数字。
- 进行除以"0"的计算。

### 规格

电源：太阳能及锂电池 (CR2032 x1)  
 工作温度范围：摄氏0至40度  
 自动断电：约7分钟  
 体积：185(长)x154(宽)x42(高) 毫米  
 重量：264克  
 产品标准：GB/T4967-1995  
 本使用说明书的规格及内容如有改动，恕不另行通知

- Before using this product, please read this manual carefully. And keep it on hand for future reference.

### ⚠ CAUTION

- Avoid using, placing or storing the calculator in places subject to strong sunlight, rapid temperature change, humid or dusty areas.
- Use a dry cloth to clean the casing of the unit. Do not use water, organic solvents or detergents.
- Avoid using the calculator in places where there are iron filings, as this may affect the electrical circuits of the calculator.
- Do not twist or bend or attempt to open the calculator.
- Lack of electricity may cause damage or failure of memory content, please reset the calculator.

### POWER SUPPLY

This calculator has two power sources: battery and solar. The duration of the battery depends on individual usage.

- ⚠ Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the contents the memory to be lost or altered. Should this occur, press the  $\text{ON/C}$  key and re-start your calculation from the beginning.

### OVERFLOW FUNCTIONS

In the following cases, error message (E) will be shown on the display. The keyboard is electronically locked, and further operation is impossible. Press  $\text{ON/C}$  to clear the overflow. The overflow occurs when:

- The result or the memory content exceeds 12 digits to the left of the decimal point.
- Dividing by "0".

### SPECIFICATIONS

Power Source: Solar cell and Lithium battery (CR2032 x 1)  
 Operating Temperature : 0°C to 40°C  
 Automatic Power-off : approx. 7 minutes  
 Dimension: 185(L) x 154(W) x 42(H) mm  
 Weight : 264g  
 All specifications and contents of this instruction are subject to change without notice

# Canon

## 佳能计算器系列保证书

本产品是在严格的质量控制和质量检验下生产的优良产品。本保证书是指该产品在保证期间内正常使用下，发生故障时，本公司给予免费维修及调整。

商品名称			
保修期限	以购买日起	年	月 日 1年内有效
顾客	姓名：	电话号码：	
	地址：	邮政编码：	
经销商名称	地址：		
	电话号码：	邮政编码：	
<b>保证规定</b>			
1. 以购买日起，在正常使用情况下发生故障时，可得到一年的保修服务。但人为破坏(如人为拆卸零件不当，外力损坏等)。自然损坏(如火灾、地震、水灾、鼠害等自然灾害)所引起的损坏，不属于此保修范围。			
2. 消耗品(如电池等)及配件的更换，不属于本保证书的保修范围。			
3. 本保证书一旦遗失不再补发，请务必妥善保管。			
4. 由于消费者本身使用不当所引起的故障不给予免费保修服务。			
5. 产品已逾保修年限发生故障，如本公司尚有配件，则给予维修服务，酌收一定的零件费及手续费。			
6. 本保证书只在中华人民共和国境内有效。			
<b>厂商名称及地址</b> 佳能电产香港有限公司 香港新界葵涌货柜码头路八十二至一百号永得利广场第一期十七楼 <b>销售商名称及地址</b> 北京通泰嘉怡科技有限责任公司 北京市西城区北展北街华远企业中心D座1单元505室 电话：010-88320775 传真：010-88320776 电邮：admin@bjbroadwin.com.cn			

## 产品中有害物质的名称及含量

**表二**

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
线路板	○	○	○	○	○	○
电子零件	×	○	○	○	○	○
外壳	○	○	○	○	○	○
电池	○	○	○	○	○	○
显示器	○	○	○	○	○	○
结构零件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制

- ：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。  
 ×：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。



本标志适用于在中华人民共和国销售的电子电气产品，标志中央的数字代表产品的环保使用期限。只要您遵守与本产品相关的安全与使用方面的注意事项，从生产日期起算的上述年限内，就不会产生环境污染或对人体及财产的严重影响。