



E-IM-2714

电子计算器/  
Electronic Calculator

运算/ Calculation 	操作/ Operation 	显示/ Display 
<b>▼ 混合运算/Mixed</b> 140-35+22=127 $2 \times 2 \textcircled{3} = 6$ $-7 \times 9 \textcircled{8} = -63$ $(2+4) \times 3 \times 8.1 = 16.2$		
<b>▼ 份数/Fraction</b> $3^4 = 81$ $1/5 = 0.2$ $1/(2 \times 3 + 4) = 0.1$		
<b>▼ 平方根/Square root</b> $\sqrt{3} = 1.73205080756$		
<b>▼ 百份比/Percentage</b> $1,200 + (1200 \times 20\%) = 1,440$ $1,200 - (1,200 \times 20\%) = 960$		
<b>▼ 记忆运算/Memory</b> $3 \times 4 = 12$ -) $60 \div 0.2 = 30$ -18 +)     200 182		
<b>▼ 总计运算/Grand Total</b> $30 \times 40 = 1,200$ +) $50 \times 60 = 3,000$ 4,200 +) $23 \times 35 = 805$ 5,005		

运算/ Calculation 	操作/ Operation 	显示/ Display 
<b>▼ 商业运算/Business Calculation</b> <b>成本计算/Calculating of Cost</b> 销售价/Selling Price: \$2,000 利润差额/Profit Margin: 30% 成本/Cost=? (\$1,400)		
<b>销售计算/Calculating of Selling Price</b> 成本/Cost: \$1,500 利润差额/Profit Margin: 20% 销售价/Selling Price=? (\$1,875)		
<b>利润差额计算/Calculating of Profit Margin</b> 成本/Cost: \$1,500 销售价/Selling Price: \$2,000 利润差额/Profit Margin=? (25%)		
<b>▼ 溢出/Overflow</b> 1) 123456789 x 78900 =9740740652100 (溢出/ERROR)		
2) 99999999999999999999 (记忆/add to memory) 123 (记忆/add to memory)		
3) $6 \div 0 = 0$ (溢出/ERROR)		

佳能电产香港有限公司  
 香港新界葵涌货柜码头路82-100号永得利广场第一期17楼  
 北京博怡嘉业科技股份有限公司  
 北京市西城区北展北街华远企业中心D座1单元505室

■ 使用本产品前，请务必阅读本使用说明书；保留备用；理解本说明书的内容后，请正确使用。

## 商业总额运算

**COST** **SELL** **MARGIN**

用于计算成本，销售及利润额。输入任意两项之数值，即可获得差额值(如，输入成本数值及销售价即可获得利润额。)

### ⚠ 使用建议和注意事项

- 太阳能供电组件最低需要在50勒克斯(Lux)的光照亮度环境下操作。
- 请确保太阳能电池板没有被盖着。
- 计算器在光照亮度不足的情况下操作，启动和运算时间或会较长。
- 在光照亮度不足的情况下使用记忆运算，记忆内容或不被存储或丢失。

### 困难问题的处理方法

问题信息/困难	处理方法
<ul style="list-style-type: none"> <li>• 错误或溢出：当“E”显示时，键盘会以电子方式锁住，并且不允许进一步操作。</li> </ul>	按 <b>ON</b> 键，以清除溢出及再启动计算器。
<ul style="list-style-type: none"> <li>• 当显示的字元变得模糊或不稳定。</li> <li>• 屏幕不能显示或记忆体不能存储(可能是电磁干扰或静电放电而引起)。</li> </ul>	<ol style="list-style-type: none"> <li>1. 请检查及确保太阳能电池板没有被盖着。</li> <li>2. 将计算器放置在较光量的地方操作。</li> <li>3. 按 <b>ON</b> 键。</li> </ol>

附注：本计算器显示屏幕，使用佳能数码相机光学组件之生产剩余塑料，循环再生。可能会出现黑点或颜色不均的情况。

### 规格

电源：太阳能(太阳光或灯光) ≥ 50勒克斯(Lux)

自动断电：约七分钟

操作温度：0 至 40度

体积：157毫米(长) × 95.2毫米(宽) × 13.5(高) / 重量：205克

(规格如有任何改动，恕不另行通知)

■ Before using the product, please read this manual carefully. And keep it on hand for future reference.

## BUSINESS CALCULATION

**COST** **SELL** **MARGIN**

Used for calculating the cost, selling price and profit margin percentage and profit amount. Enter the value of any 2 items to obtain the balance value item. (e.g. enter the value of the cost and the selling price to obtain the profit margin %)

### ⚠ HANDLING AND PRECAUTION

- The solar cell requires at least 50 lux of light to generate power for operation.
- DO NOT cover any part of the solar cell panel.
- When the calculator operates in a dim environment, the time for machine start-up or calculation might increase.
- The independent memory might not be retained when solar power is insufficient.

### IN CASE OF DIFFICULTIES

Symptoms/Difficulties	Solution
<ul style="list-style-type: none"> <li>• Error or Overflow: When “E” is displayed, the keyboard is electronically locked, and further operation is not possible.</li> </ul>	Press <b>ON</b> key to restart the calculator.
<ul style="list-style-type: none"> <li>* Display becomes dim, not stable.</li> <li>* Display content fails to appear or memory content is lost or altered (maybe caused by electromagnetic interference or electrostatic source discharge)</li> </ul>	<ol style="list-style-type: none"> <li>1. Check and make sure solar panel is not covered.</li> <li>2. Move calculator (solar panel) to brighter light.</li> <li>3. Press <b>ON</b> key.</li> </ol>

NOTES : This calculator display panel is made from Canon Digital Cameras Recycled pre-consumer material which might have black dot or uneven color.

### SPECIFICATION

Power Source: Solar (Sun/Light) ≥ 50lux

Automatic power-off: approx. 7 minutes

Operation Temperature: 0°C to 40°C

Dimensions: 157mm (L) × 95.2mm (W) × 13.5mm (H) / Weight: 205g

(This manual data is subject to change without notice.)