



www.canon.com/calcmannual



E-IM-2996

INSTRUCTIONS **EN**  
사용설명서 **KR**

Calculation Examples / 계산 예

Calculation / 계산	Operation / 작동법	Display/ 디스플레이
<b>▼ Mixed / 혼합계산</b>	<b>ON/CA</b>	( 0.)
140-35+22=127	140 <b>[-]</b> 35 <b>+</b> 22 <b>=</b>	( 127.)
2 x 2 = 6	2 <b>[x]</b> 2 <b>=</b>	( 6.)
(2+4) ÷ 3 x 8.1 = 16.2	2 <b>+</b> 4 <b>=</b> 3 <b>[x]</b>	( 16.2)
-7 x 9 = -63	7 <b>[+/-]</b> <b>[x]</b> 9 <b>=</b>	( -63.)
<b>▼ Constant / 상수</b>		
2+3=5	2 <b>+</b> 3 <b>=</b>	( 5.)
4+3=7	4 <b>+</b> 3 <b>=</b>	( 7.)
1-2=-1	1 <b>[-]</b> 2 <b>=</b>	( -1.)
2-2=0	2 <b>[-]</b> 2 <b>=</b>	( 0.)
2x3=6	2 <b>[x]</b> 3 <b>=</b>	( 6.)
2x4=8	2 <b>[x]</b> 4 <b>=</b>	( 8.)
6÷3=2	6 <b>[÷]</b> 3 <b>=</b>	( 2.)
9÷3=3	9 <b>[÷]</b> 3 <b>=</b>	( 3.)
<b>▼ Power, Fraction / 제곱, 분수/소수</b>		
3 <sup>4</sup> = 81	3 <b>[x]</b> <b>[x]</b> <b>[x]</b> <b>[x]</b> <b>=</b>	( 81.)
1/5 = 0.2	1 <b>[÷]</b> 5 <b>=</b>	( 0.2)
1/(2x3+4) = 0.1	2 <b>[x]</b> 3 <b>+</b> 4 <b>[÷]</b> <b>=</b>	( 0.1)
<b>▼ Percentage / 백분율</b>		
1200x12% = 144	1200 <b>[x]</b> 12 <b>[%]</b> <b>=</b>	( 144.)
1200x20% = 240	1200 <b>[x]</b> 20 <b>[%]</b> <b>=</b>	( 240.)
<b>▼ Square Root / 제곱근</b>		
√3 = 1.73205080756	3 <b>[√]</b>	( 1.73205080756)
<b>▼ Memory / 메모리</b>	<b>ON/CA</b>	( 0.)
3x4 = 12	3 <b>[x]</b> 4 <b>[M+]</b>	(M 12.)
-) 6 ÷ 0.2 = 30	6 <b>[÷]</b> 0.2 <b>[M+]</b>	(M 30.)
-18	<b>[RM CM]</b>	(M -18.)
+) 200x2 = 400	200 <b>[x]</b> 2 <b>[M+]</b>	(M 400.)
382	<b>[RM CM]</b> (Recall Memory / 메모리 호출)	(M 382.)
	<b>[RM CM]</b> (Clear Memory / 메모리 소거)	( 382.)

Calculation / 계산	Operation / 작동법	Display/ 디스플레이
<b>▼ Tax Calculation / 세금 계산</b>		
<b>Tax Rate Set</b> Tax Rate = 5%	<b>ON/CA</b> <b>SET</b> 5 <b>SET</b>	( TAX% 0.) ( TAX% 5.)
<b>Add the Tax Amount</b> Price \$2,000 without tax Selling price with tax? (\$2,100) Tax amount? = (\$100)	2000 <b>TAX+</b> <b>TAX+</b>	( 2'000.) ( TAX+ 2'100.) ( TAX 100.)
<b>Deduct Tax Amount</b> Selling price \$3,150 with tax Price without tax? (\$3,000) Tax amount? = (\$150)	3150 <b>TAX-</b> <b>TAX-</b>	( 3'150.) ( TAX- 3'000.) ( TAX 150.)
<b>Recall Tax Rate</b>	<b>ON/CA</b> <b>RECALL</b>	( TAX% 5.)
<b>▼ Grand Total / 총계</b>	<b>ON/CA</b>	( 0.)
30x40 = 1,200	30 <b>[x]</b> 40 <b>=</b>	( GT 1'200.)
50x60 = 3,000	50 <b>[x]</b> 60 <b>=</b>	( GT 3'000.)
+) 25x30 = 750	25 <b>[x]</b> 30 <b>=</b>	( GT 750.)
4,950	<b>GT</b> (Grand Total / 총계 소거) <b>GT</b> (Clear Grand Total Memory / 총계)	( GT 4'950.) ( 4'950.)
<b>▼ Overflow / 오버플로우</b>		
1) 123456789x78900 =9740740652100 (Error/오류)	<b>ON/CA</b> 123456789 <b>[x]</b> 78900 <b>=</b> <b>[ON]</b> <b>ON/CA</b>	( 0.) ( E 9.74074065210) ( 9.74074065210) ( 0.)
2) 6 ÷ 0 = 0 (Error/오류)	6 <b>[÷]</b> 0 <b>=</b> <b>[ON]</b>	( E 0.) ( 0.)

**CANON ELECTRONIC BUSINESS MACHINES (H.K.) CO., LTD.**  
17/F., Tower One, Ever Gain Plaza,  
82-100 Container Port Road, Kwai Chung,  
New Territories, Hong Kong

**CANON KOREA BUSINESS SOLUTIONS INC.**  
607, Teheran-ro, Gangnam-gu, Seoul, Korea  
www.canon-bs.co.kr

Made in China / 중국 제조 업체  
Printed in China / 인쇄지: 중국

ENGLISH

**IMPORTANT: READ BEFORE USE**  
Please read the following instructions before using the calculator. Keep this sheet on hand for future reference.

**POWER SUPPLY**  
This calculator comes with a dual power source. The duration of alkaline battery depends on individual usage.  
**(Note: Do not attempt to change the battery by yourself. Have a Canon Service Center change the battery for you.)**

**!** Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the contents of the memory to be lost or altered. Should this occur, press the **ON/CA** key and re-start your calculation from the beginning.

**AUTOMATIC POWER-OFF FUNCTION**  
When the power is turned "ON" and none of the keys are pressed more than 7 minutes, the calculator turns off automatically to save power. Press the **[ON]** key to the calculation.

**TAX FUNCTION**  
**ON/CA** **SET** **Store the tax rate** – Press **ON/CA** **SET** and enter the tax rate, then press **SET** to store.  
**ON/CA** **RECALL** **Recall the tax rate** – Press **ON/CA** **RECALL** to recall the stored tax rate.  
**TAX+** **Add tax key** – Used for adding the tax amount to the display figure.  
**TAX-** **Deduct tax key** – Used for deducting the tax amount from the displayed figure.

**GRAND TOTAL FUNCTION**  
**GT** The totals are accumulated in the grand total memory. Press **GT** to get the grand total. Press **GT** successively to clear the grand total memory

**OVERFLOW FUNCTION**  
In the following cases, when "E" is display, the keyboard is electronically locked, and further operation is impossible. Press **[ON]** to clear the overflow. The overflow function occurs when:  
1) The result or the memory content exceeds 12 digits to the left of the decimal point.  
2) Dividing by "0".

**SPECIFICATION**  
Power Source: Solar cell and alkaline battery (LR44x 1)  
Operation Temperature: 0°C to 40°C  
Dimensions: 145mm (L) x 104mm (W) x 25mm (H)  
Weight: 119 g  
(Subject to change without notices)

한국어

**중요 : 사용하기 전에 반드시 읽어**  
계산기를 사용하기 전에 다음 지침을 읽어 보시기 바랍니다. 나중에 참조 할 수 있도록 손이 시트를 유지합니다.

**전원**  
본 제품은 이중 전원으로 구성되어 있습니다. 알칼리 전지의 지속 시간은 각각의 사용에 의존한다.  
**(노트: 직접 배터리를 교체하지 마십시오. 캐논 서비스 센터가 당신을 위해 배터리를 교체해야 합니다.)**

**!** 전자기 간섭 또는 정전기 방전은 표시가 오작동을 일으킬 수 있거나 또는 메모리의 내용이 손실되거나 변경된다. 이 발생할 경우, **ON/CA** 키를 누르면 처음부터 당신의 계산을 다시 시작합니다.

**자동 전원 끄기 기능**  
전원을 "ON"으로 설정하고 때 키 중 어느 것도 7 개 이상의 분 누르지, 계산기는 전원을 절약하기 위해 자동으로 꺼집니다. 계산에 **[ON]** 키를 누르십시오.

**세금 기능**  
**ON/CA** **SET** 세율을 저장 – **ON/CA** **SET** 을 눌러 및 세율을 입력 한 다음 저장소에 **SET** 를 누르십시오.  
**ON/CA** **RECALL** 세율 리콜 – **ON/CA** **RECALL** 을 눌러 저장 세율을 불러옵니다.  
**TAX+** 세금 키를 추가합니다 – 디스플레이 그림에 세액을 추가하는 데 사용됩니다.  
**TAX-** 세금 키를 공제 – 표시된 그림에서 세액을 공제에 사용됩니다.

**총계 기능**  
**GT** 계산 총계가 총계 메모리에 합산 저장됩니다. **GT** 키를 눌러 총계를 불러옵니다. 연이어 **GT** 를 눌러 총계 메모리를 소거합니다.

**오버플로우 기능**  
오버플로우가 발생하면 영문자 "E"가 디스플레이에 나타나면서 키보드가 전자적으로 잠금 상태로 전환되어 더 이상 작동이 불가능해집니다. **[ON]** 키를 눌러 오버플로우 상태를 해제해야 합니다. 오버플로우 기능이 발생하는 경우는 다음과 같습니다.  
1) 계산 결과 또는 메모리 내용이 소수점 왼편 12 자리를 초과하는 경우.  
2) "0"으로 나눈 경우.

**제품 사양**  
전원: 태양 전지 및 알칼리성의 배터리 (모델: LR44 ) 1개  
작동 온도 : 0°C ~ 40°C  
크기: 145mm (L) x 104mm (W) x 25mm (H)  
중량: 119 g  
(위 사양은 공지 없이 변경될 수 있습니다)