

E Calculation Examples

S Ejemplos de cálculos

+ - x ÷		
$(8+3)4.5=49.5$	8 + 3 x 4.5 =	49.5
$2+8+3=3.25$	2 + 8 + 3 =	3.25
$2 \times 3=6$	2 x 3 =	6.
$7 \times 9=63$	7 x 9 =	63.
$2+3=5$	2 + 3 =	5.
$4+3=7$	4 + 3 =	7.
$1-2=-1$	1 - 2 =	1. — MINUS
$2-2=0$	2 - 2 =	0.
$2 \times 3=6$	2 x 3 =	6.
$2 \times 4=8$	2 x 4 =	8.
$6 \div 3=2$	6 ÷ 3 =	2.
$9 \div 3=3$	9 ÷ 3 =	3.
$3^4=81$	3 x = = =	81.
$1/5=0.2$	5 ÷ =	0.2
$1/(2 \times 3 + 4)=0.1$	2 x 3 + 4 ÷ =	0.1
√ Square Root / Raíces cuadradas		
$\sqrt{324}=18$	324 √	18.
$\sqrt{(4+5) \times 9}=9$	4 + 5 x 9 = √	9.

%± Percentage / Porcentajes

$200 \times 17\%=34$	200 x 17 %±	34.
$200 \times 19\%=38$	200 x 19 %±	38.
$200+(200 \times 20\%)=240$	200 + 20 %±	240.
$200-(200 \times 20\%)=160$	200 - 20 %±	160.

RM CM M± M= Memory / Memoria

$20 \times 30=600$	20 x 30 M±	MEMORY 600.
$6,000 \div 15=400$	6000 ÷ 15 M±	MEMORY 400.
$+) 15 \times 20=300$	15 x 20 M±	MEMORY 300.
$1,300$	RM	MEMORY 1300.
$-) 125 \times 40=5,000$	125 x 40 M±	MEMORY 5000.
$-3,700$	RM	— MINUS MEMORY 3700.
	CM	— MINUS 3700.

■ Overflow / Bloqueo por capacidad exce

$12,345,678 \times 9,876$	12345678 x 9876 =	ERROR 1219,2591
$=121,925,915,928$	121925915928 ON C	0.
$33,333,333 \times 3$	33333333 x 3 M±	MEMORY 99999999.
$=99,999,999$	123 x 456 M±	MEMORY ERROR 0.
123×456	ON C	MEMORY 0.
$+) =56,088$	RM	MEMORY 99999999.
$100,058,087$	CM	99999999.
$7 \div 0=0$ (Error) ↓	7 ÷ 0 =	ERROR 0
	ON C	0

Fuente de energía

Español

Esta calculadora puede funcionar con dos fuentes de alimentación: fotocelda solar o pilas alcalinas. Generalmente, bajo condiciones de iluminación normal en una sala, la calculadora podrá funcionar con la fotocelda solar. Cuando la intensidad de iluminación disminuya más allá de un valor determinado, la calculadora pasará a utilizar automáticamente las pilas alcalinas.

Las pilas alcalinas pueden utilizarse durante bastante tiempo, dependiendo del uso que se les dé. Cuando se agoten las pilas usted podrá utilizar aún la pila solar para que funcione la calculadora.

(Nota: No trate de cambiar usted mismo las pilas. Acuda a un centro de servicio Canon para que le cambien las pila.)

Función de desconexión automática

- 7 minutos aproximadamente.
- En este caso, presione le tecla ON/C para comenzar los cálculos. "0" aparecerá en el indicador. No afecta el contenido de la memoria.

Observaciones

- Asegúrese de presionar la tecla ON/C antes de iniciar los cálculos.
- Borre el error por capacidad excedida oprimiendo la tecla ON/C .

Canon

LS-555H

INSTRUCTIONS
INSTRUCCIONES

English

Power Supply

This calculator comes with a dual power source, either solar cell or alkaline battery.

Generally, under normal room lighting, the calculator is powered by a built-in solar cell.

The alkaline batteries can be used for quite a long time depending on individual usage. When the battery is dead, you can still use the solar cell to power the calculator.

(Note: Do not attempt to change the battery by yourself. Have a Canon Service Center change the battery for you.)

Automatic power off function

- When the calculator is turned on but none of the keys are pressed for more than approx. 7 minutes, the display goes out automatically.
- In this case, press the ON/C key to start the calculation. "0" will appear in the display.

Note

- Be sure to press the ON/C key before starting calculation.
- Clear the overflow error by pressing the ON/C key.



E-IM-3400

CANON CONSUMER CALCULATOR LIMITED WARRANTY

The limited warranty set forth below is given by Canon U.S.A., Inc., (Canon U.S.A.) with respect to Calculators purchased and used in the United States respectively.

This limited warranty is only effective upon presentation of proof of purchase (bill of sale) to Canon U.S.A. Factory Service Center. Canon Calculators, when delivered to you in a new condition in the original container, are warranted against defective materials or workmanship as follows: for a period of one (1) year from the date of original purchase, defective parts or Calculators returned to a Canon U.S.A. Factory Service Center and proven to be defective upon inspection, will be exchanged at Canon U.S.A.'s sole option, for new or comparable rebuilt parts or calculators (of the same or similar model). Warranty for replacement shall not extend the original warranty period of the defective calculator.

When returning Calculators under this limited warranty, you must pre-pay the shipping charges, if any, and enclose a complete explanation of the problem. Calculators covered by this limited warranty will be repaired at Canon U.S.A.'s sole option, and returned to you without charge by any Canon U.S.A. Service Center. This warranty does not cover rechargeable batteries that may be supplied with the Calculator, as to which batteries there shall be no warranty or replacement.

Information Technology Services Center will refer you to the nearest Factory Service Center. Repairs not under warranty will be at such cost as Canon U.S.A. may from time to time generally establish.

This limited warranty covers all defects encountered in normal use of the calculators, and does not apply in the following cases:

- Loss or damage to the Calculators due to abuse, mishandling, alteration, accident, electrical current fluctuations, failure to follow operating instructions, maintenance and environmental instructions prescribed in Canon U.S.A.'s instruction manual or service performed by other than a Canon U.S.A. Factory Service Center.
- Use of parts (other than those distributed by Canon U.S.A. which damage the Calculator or cause abnormally frequent service calls or service problems.
- If any Calculator has had its serial numbers or dating altered or removed.
- Loss or damage to the Calculator due to leaking batteries (other than rechargeable batteries supplied as original equipment with the Calculator by Canon U.S.A. or water damage.

NO IMPLIED WARRANTY (OR CONDITION)* INCLUDING ANY IMPLIED WARRANTY (OR CONDITION)* OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, APPLIES TO THE CALCULATORS AFTER THE APPLICABLE PERIOD OF EXPRESS WARRANTY STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTY, EXCEPT AS MENTIONED ABOVE, GIVEN BY ANY PERSON, FIRM OR CORPORATION WITH RESPECT TO THE CALCULATORS SHALL BIND CANON U.S.A. (SOME STATES OR PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.) NEITHER CANON U.S.A. SHALL BE LIABLE FOR LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, OR FOR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE CALCULATOR, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF CANON U.S.A. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVERY OF ANY KIND AGAINST CANON U.S.A. BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE CALCULATOR SOLD BY CANON U.S.A. AND CAUSING THE ALLEGED DAMAGE. WITHOUT LIMITING THE FOREGOING, YOU ASSUME ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO YOU AND YOUR PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF USE, MISUSE OR INABILITY TO USE ANY CALCULATOR SOLD BY CANON U.S.A. OR CANON CANADA NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF CANON U.S.A. OR CANON CANADA. (SOME STATES OR PROVINCES

DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.) THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF ANY CALCULATOR OR THE PERSON FOR WHOM IT WAS PURCHASED AS A GIFT AND STATES YOUR EXCLUSIVE REMEDY.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

Canon U.S.A., Inc.
One Canon Park, Melville, NY 11747

Canon Information Technology Services in the United States
For all general inquiries, operational assistance, accessory orders or for the location of the nearest service facility for this product in the United States, please contact:

Canon U.S.A., Inc.
One Canon Park, Melville, NY 11747
Customer Relations Division
1-800-828-4040

Please keep a copy of your original bill of sale. In order to obtain warranty service, you will need to present a copy of your original bill of sale from your Consumer Calculator retailer at the time of service.

Also please keep all packing materials and the original packing box to protect your equipment, should you need to transport it for service.

BATTERY CAUTION

- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Battery type : LR1130 (1.5V)
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above (30°C) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

CANON ELECTRONIC BUSINESS MACHINES (H.K.) CO., LTD.

17/F., Tower One, Ever Gain Plaza,
82-100 Container Port Road, Kwai Chung,
New Territories, Hong Kong

CANON U.S.A., INC.

One Canon Park, Melville, NY 11747, 1-800-OK-CANON

Made in China / Hecho en China
Printed in China / Impreso en China

E-IM-3400

© CANON ELECTRONIC BUSINESS MACHINES (H.K.) CO., LTD. 2024

For USA only



WARNING

- INGESTION HAZARD:** This product contains a button cell or coin battery.
- DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical Burns** in as little as **2 hours**.
- KEEP** new and used batteries **OUT OF REACH** of CHILDREN.
- Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of body.

