LC-210Hi III

使用说明书
INSTRUCTIONS

请沿背面指示剪开礼盒，说明书，运算例子及重要事项，印刷在内。
Cut as shown on the back to see the calculation example and important notes inside the box.

E-IM-2560

运算例子 / Calculation Example

	运算 / CALCULATION	操作 / OPERATION	显示 / DISPLAY
+ − × ÷	**▼ 混合运算 / Mixed**		
	140−35+22=127	[ON/C] 140 [−] 35 [+] 22 [=]	(0.) (127.)
	2×⅓=6	2 [×] 2 [÷] 3 [=]	(6.)
	−7×9=−63	[ON/C] [−] 7 [×] 9 [=]	(− 63.)
	(2+4)÷3×8.1=16.2	2 [+] 4 [+] 3 [×] 8 [(] 1 [=]	(16.2)
	▼ 常算运算 / Constant		
	2+3=5	2 [+] 3 [=]	(5.)
	4+3=7	4 [=]	(7.)
	1−2=−1	1 [−] 2 [=]	(− 1.)
	2−2=0	2 [=]	(0.)
	5×3=15	5 [×] 3 [=]	(15.)
	5×4=20	4 [=]	(20.)
	6÷3=2	6 [÷] 3 [=]	(2.)
	9÷3=3	9 [=]	(3.)
	▼ 份数 / Power, Fraction		
	3^3=27	3 [×] [=] [=]	(27.)
	1/2=0.5	2 [÷] [=]	(0.5)
√	**▼ 平方根 / Square Root**		
	$\sqrt{3}$ = 1.7320508	3 [√]	(1.7320508)
%±	**▼ 百份比 / Percentage**		
	1,200x12%=144	1200 [×] 12 [%±]	(144.)
	200+(200x20%)=240	200 [+] 20 [%±]	(240.)
	200−(200x20%)=160	200 [−] 20 [%±]	(160.)
M±	**▼ 记忆运算 / Memory**		
	3 x 4 = 12	[RM/CM] [RM/CM] [ON/C]	(0.)
	−) 6 ÷ 0.2 = 30	3 [×] 4 [M±]	(M 12.)
MR	−18	6 [÷] [(] 2 [M±]	(M 30.)
	+) 200	[RM/CM]	(M 18.)
	182	200 [M±]	(M 200.)
RM/CM		[RM/CM] (Recall Memory)	(M 182.)
		[RM/CM] (Clear Memory)	(182.)
	▼ 溢出 / Overflow		
	123456x7890= 97406784 0 (溢出/ERROR)	123456 [×] 7890 [=]	(E 9.7406784) (0.)
	6÷0 = 0 (溢出/ERROR)	6 [÷] 0 [=]	(E 0.) (0.)

中国印制　　修订日期: 2011.03

佳能电产香港有限公司
香港新界葵涌货柜码头路八十二至一百号永得利广场第一期十七楼
佳能(中国)有限公司
中国北京东城区金宝街89号金宝大厦15层
电话: (010) 8513 9999

中 国 语

■ 在使用本产品前，请务必先仔细阅读本使用说明书。

电源

本计算器使用碱性电池。 碱性电池的使用时间完全取决于个别的使用情况。

（**注**： 不要试图自行更换电池，请到佳能维修服务中心，专业人员为您更换电池。）

■ 电磁干扰或静电放电可引起显示故障或内存中的内容丢或改变。若出现此情况，请按 [ON/C] 键重新开始计算。

规格

电　　源：碱性电池 (LR1130 x 1)
自动断电：约 **8 分钟**
操作温度：0 至 40 度 (华氏 32 至 104 度)
体　　积：97 毫米 (长) x 60 毫米 (宽) x 11.4 毫米 (高)
重　　量：41克
（规格如有改动恕不另行通知）

ENGLISH

POWER SUPPLY

This calculator comes with an alkaline power source.
The alkaline battery,is long lasting however the battery life will depend on usage.

(**Note:** Do not attempt to change the battery. Please have a Canon Service Center technician change the battery)

■ Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the contents of the memory to be lost or altered. Should this occur, press the [ON/C] key and re-start your calculation from the beginning.

SPECIFICATION

Power Source : Alkaline battery (LR1130 X 1)
Automatic power-off function: Approx. **8 minutes**
Usable Temperature : 0ºC to 40ºC (32ºF to 104ºF)
Dimensions : 97mm (L) x 60mm (W) x 11.4mm (H) / 3-53/64" (L) x 2-3/8" (W) x 29/64" (H)
Weight : 41g (1.45oz)
(Subject to change without notices)

注: 部分塑胶采用佳能产品的再生塑料，可能会出现黑点或塑料颜色不均的情况

Note: Some plastic parts are made from recycled material of Canon product which might have black dot(s) or uneven plastic color.