

CT-40

Timer Clock/ Jam Timer/
Đồng hồ Hẹn giờ



E-IM-2894

Instructions
EN
IN
VI


IMPORTANT: READ BEFORE USE ENGLISH

- When using this product, please read all the operating instructions, warnings and precautions provided by Canon.
- After reading this manual, please keep it for future reference.

WARNING: This product is embedded with magnets at the back. Please be careful if implant electronic devices (such as cardiac pacemaker) nearby, as magnets may cause malfunctions. If this happens, please distance the magnet from the implant electronic device and consult the doctor at once.

INITIAL SETUP INSTRUCTIONS

- Remove the insulation tape (①) and press [RESET] button at the back side of the unit before use.
- Press **MODE** to select the function mode in the following order:
Clock → Alarm → Count up → Timer → Back to Clock.



TIME SETTING

Example: 3:45PM (24-hours basis 15:45)

- Go to Clock mode: Press **MODE** until "CLOCK" icon appear on the display.
- Enter the time by pressing number keys. ①⑤④⑤①①
 - Set the Hours, Minutes, Seconds in 24-hour basis.
 - The time will blink in time setting mode.
- Press **START/STOP** to confirm the time.
 - Use **12/24** to switch between 12 or 24 hour format.



ALARM CLOCK SETTING

Example: alarm timer at 7:15 AM

- Go to Alarm mode: Press **MODE** until "A.CLOCK" icon appear on the display.
- Enter the time by pressing number keys. ⑦①⑤①①
 - The time will blink in setting mode.
- Press **START/STOP** to confirm and activate the Alarm.
 - bell** will appear on the display when Alarm is ON.
 - Press **START/STOP** to switch Alarm ON or OFF.
- To stop the Alarm, simply press **START/STOP** once.



TIMER

- Go to Timer mode: Press **MODE** until "TIMER" icon appear on the display.
- Set the Timer using number keys.
(up to a maximum of 9 hours, 59 minutes and 59 seconds)
- Press **START/STOP** to confirm and start the timer.
- To reset the timer; make sure the running time is stopped by pressing **START/STOP** once, then press **CLEAR** to resume last timer and key in the new time.
- When timer reaches 0:00:00, the alarm will ring for about 1 minute, the time will blink and start to count up.



COUNT-UP TIMER

- Press **MODE** to select Count-Up mode.
"COUNT UP" icon will be shown.
- Press **START/STOP** to start the count-up.
(Timer can count-up to a maximum of 9 hours, 59 minutes, 59 seconds).
- Press **START/STOP** to pause or stop the count-up. To continue the count-up, simply press **START/STOP** once.
- To reset the count-up timer, press **CLEAR** right after the count-up timer is stopped.



QUICK TIMER

- In any mode, simply press **Q** to activate Quick Timer mode. Then "Q" icon will blink.
- While "Q" icon is blinking, set the timer (from 1 to 9 minutes) by pressing one of the number key (exclude 0).
- Timer will start immediately and "Q" will change into "Q.TIMER".
- When timer reaches 0:00:00, the alarm will ring for about 1 minute.

TIPS & CAUTIONS


- Press and hold **Q** for 2 seconds in any mode to turn key-touch and alarm sound ON or OFF. **Q** will appear when key-touch and alarm sound is OFF.
- The alarm sound will continue for about 1 minute unless the **START/STOP** key is pressed.
- In timer and quick timer mode, alarm can be stop by any key.
- When timer/ quick timer/ count-up timer is started and then switch to other mode, the mode icon ("TIMER" / "Q.TIMER" / "COUNT UP") will blink continuously.
- When setting time or alarm with inappropriate input, error message will be shown. Press **CLEAR** to clear the error message.
- When the timer reaches the maximum measurement timer (9 hours, 59 minutes and 59 seconds) in "Timer" or "Count-up Timer" mode, "UP" message will be shown.



- In Time or Alarm setting mode, if no input for 5 seconds when display is blinking, the machine will exit the setting mode.

BATTERY REPLACEMENT

- When the alarm sound becomes weak or the display becomes dim, follow below steps and change to a new battery. Be sure to install new battery with "+" side facing up.



- After replacing the battery, use the tip of a ball point pen (or similar sharp object) to press the [RESET] button behind the stand. Then, set the time again.



CAUTION

- Keep the battery out of the reach of children. If the battery is swallowed, contact a doctor immediately.
- Never expose the battery to high temperatures, direct heat, or dispose by incineration.
- Never leave a dead battery in the timer as the dead battery may leak and cause damage to the timer.
- If a battery leaks, remove the battery, be careful to keep the leaked fluid from touching your skin or clothes. If fluid from the battery comes into contact with skin or clothes, rinse skin with water immediately.

SPECIFICATIONS

Power supply	: Alkaline Battery (LR44×1)
Operation temperature	: 0°C – 40°C
Dimension	: 47mm (L) x 80mm (W) x 13.5mm (H)
Weight	: 41g (including battery)
Battery life	: About 20 Months (condition: Clock mode, Alarm: 1time/ day)
Clock accuracy	: ± 30 seconds/ month (at 25°C) (Subject to change without notice)

USING THE STAND

- To open the stand, press the button at the bottom of the machine.
- To close the stand, press lower part of the stand.



BAHASA INDONESIA


PENTING: BACA SEBELUM MENGGUNAKAN

- Ketika menggunakan produk ini, mohon dibaca semua instruksi operasi, peringatan dan perhatian yang diberikan oleh Canon.
- Setelah membaca manual ini, mohon disimpan untuk referensi.

PERINGATAN: Produk ini dilengkapi dengan magnet di bagian belakang. Mohon berhati-hati jika terdapat perangkat elektronik implan (seperti alat pacu jantung) di sekitar perangkat, karena magnet dapat menyebabkan kerusakan. Jika hal ini terjadi, mohon jauhkan magnet dari perangkat elektronik implan dan hubungi dokter segera.

INSTRUKSI PENGATURAN AWAL

- Lepaskan pita isolasi (①) dan tekan tombol [RESET] di bagian belakang unit sebelum menggunakan.
- Tekan Tombol **MODE** untuk memilih fungsi mode dalam urutan berikut:
Clock → Alarm → Count up → Timer → Back to Clock.



PENGATURAN WAKTU

Contoh: 3:45PM (basis 24-jam 15:45)


- Pindah ke mode Clock (Jam): Tekan **MODE** hingga muncul ikon "CLOCK" di layar.
- Masukkan waktu dengan menekan tombol angka.
 - Atur Jam, Menit, Detik dengan basis 24-jam.
 - Waktu akan berkedip dalam mode time setting (pengaturan waktu).
- Tekan **START/STOP** untuk mengonfirmasi waktu.
 - Gunakan **12/24** untuk berpindah antara 12 atau 24 format.



PENGATURAN JAM ALARM

Contoh: waktu alarm pukul 07:15AM

- Pindah ke mode Alarm: Tekan **MODE** hingga muncul ikon "A.CLOCK" (JAM ALARM) di layar.
- Masukkan waktu dengan menekan tombol angka.
 - Waktu akan berkedip dalam mode setting (pengaturan).
- Tekan **START/STOP** untuk mengkonfirmasi dan mengaktifkan Alarm.
 - bell** akan muncul pada layar saat Alarm HIDUP.
 - Tekan **START/STOP** untuk berpindah Alarm HIDUP atau MATI.
- Untuk menghentikan Alarm, cukup tekan **START/STOP** sekali.



TIMER

- Pindah ke mode Timer: Tekan **MODE** hingga muncul ikon "TIMER" di layar.
- Atur Timer menggunakan tombol angka. (sampai maksimum 9 jam, 59 menit dan 59 detik)
- Tekan **START/STOP** untuk mengonfirmasi dan mulai timer.
- Untuk mengatur ulang timer, pastikan waktu yang sedang berjalan dimatikan dengan menekan **START/STOP** sekali, lalu tekan tombol **CLEAR** untuk melanjutkan timer terakhir dan masukkan waktu yang baru.
- Ketika timer mencapai 0:00:00, alarm akan berdering sekitar 1 menit, waktu akan berkedip dan mulai menghitung maju.



COUNT-UP TIMER

- Tekan **MODE** untuk memilih mode Count-Up (Menghitung Maju). Ikon "COUNT UP" akan ditampilkan.
- Tekan **START/STOP** untuk memulai penghitungan maju. (Timer dapat menghitung maju hingga maksimum 9 jam, 59 menit, 59 detik).
- Tekan **START/STOP** untuk menghentikan sementara atau menghentikan penghitungan maju. Untuk melanjutkan penghitungan maju, cukup tekan **START/STOP** sekali.
- Untuk mengatur ulang count-up timer, tekan tombol **CLEAR** segera setelah count-up timer dihentikan.



