Canon

KS-125WUC

E-IE-499

INSTRUCTIONS

Calculation Examples

CALCULATION	OPERATION	DISPLAY
▼ Mixed	ON CA	(0.)
140–35+22=127	140 ⊟ 35 ⊞	
	22 ⊟	(127.)
2 x 2̶ ③=6	2 ☒ 2 CI/C 3 ⊟	(6.)
7 x 99̶ = 63	7 ☒ 99 → ⊟	(63.)
9÷5x3.2+7=12.76	9 ➗ 5 ☒ 3 ●	
	2 ⊞ 7 ⊟	(12.76)
(2+4)÷3x8.1=16.2	2 ⊞ 4 ➗ 3 ☒	
	8 ● 1 ⊟	(16.2)
▼ Constant		
2+3̲=5	2 ⊞ 3 ⊟	(5.)
4+3̲=7	4 ⊟	(7.)
1–2̲=–1	1 ⊟ 2 ⊟	(– 1.)
2–2̲=0	2 ⊟	(0.)
2̲x3=6	2 ☒ 3 ⊟	(6.)
2̲x4=8	4 ⊟	(8.)
6÷3̲=2	6 ➗ 3 ⊟	(2.)
9÷3̲=3	9 ⊟	(3.)
▼ Power, Fraction		
3⁴=81	3 ☒ ⊟ ⊟ ⊟	(81.)
1/5–0.2	5 ➗ ⊟	(0.2)
1/(2x3+4)=0.1	2 ☒ 3 ⊞ 4	
	➗ ⊟	(0.1)
▼ Square root		
$\sqrt{4}$ = 2	4 √RM/CM	(2.)
▼ Percentage		
1200+(1200x20%) =1,440	1200 ⊞ 20 %±	(1'440.)
1200–(1200x20%) =960	1200 ⊟ 20 %±	(960.)

CALCULATION	OPERATION	DISPLAY
▼ Memory	ON CA	(0.)
3x4 = 12	3 ☒ 4 M±	(M 12.)
–) 6÷0.2 = 30	6 ➗ ● 2 M=	(M 30.)
–18	√RM/CM	(M – 18.)
+) 200	200 M±	(M 200.)
182	√RM/CM (Recall memory)	(M 182.)
	√RM/CM (Clear memory)	(182.)
▼ Tax		
Tax Rate Set		
Rate 1: 6%	ON CA 税率1 6 税率1	(❶ 税% 6.)
Rate 2: 10%	ON CA 税率2 5 税率2	(❷ 税% 5.)
Add the Tax Amount		
Price $2,000 without tax	2000	(2'000.)
Selling Price with tax= ? ($2,120)	税込1	(❶ 税込 2'120.)
Tax= ? ($120)	税込1	(❶ 税額 120.)
Deduct the Tax Amount		
Selling Price $3,150 with tax	3150	(3'150.)
Price without Tax = ? ($3,000)	税込2	(❷ 税抜 3'000.)
Tax= ? ($150)	税込2	(❷ 税額 150.)
Recall Tax Rate	ON CA 税抜1	(❶ 税% 6.)
	ON CA 税抜2	(❷ 税% 5.)
▼ Asian Value		
1,000 *1	ON CA メモリー 千 M=	(千 1ooo.)
	⊞	(千⊞ 1000.)
10,000,000	千 M= 万 M±	(万千 1000oooo.)
25,670,000	2 千 M= 567 万 M±	(万千 2567oooo.)
235,000	23 万 M± 5 千 M=	(万千 235ooo.)
1,023.4567 *2	千 M= 23 ● 4567	(1'023.4567.)
6,500	6 ● 5 千 M=	(65oo.)
▼ Overflow	ON CA メモリー	(0.)
1) 123456789x78900	123456789 ☒	
=9.740740652100	78900 ⊟	(E 9.74074065210)
(ERROR)	CI/C	(9.74074065210)
2) 6÷0= 0̲	6 ➗ 0 ⊟	(E 0.)
(ERROR)	CI/C	(0.)

■ IMPORTANT: READ BEFORE USE

Please read the following instruction before using the calculator. Keep this sheet on hand for future reference.

POWER SUPPLY

This calculator has two power sources: battery and solar. The duration of the battery depends on individual usage.

(!) Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the contents of the memory to be lost or altered. Should this occur, press the ᴏɴ[CA] key and re-start your calculation from the beginning.

TAX FUNCTION

This calculator has 2 Taxes Rates Memory.

ᴏɴ[CA] [税込1]
(or [税込2])

Store the tax rate: Press ᴏɴ[CA] [税込1] or [税込2] and enter the tax rate figure, then press [税込1] or [税込2] to store.

ᴏɴ[CA] [税抜1]
(or [税抜2])

Recall the tax rate: Press ᴏɴ[CA] [税抜1] or [税抜2] to recall the current tax rate.

[税込1] or [税込2]

Add tax key: Used for adding the tax amount to the display figure.

[税抜1] or [税抜2]

Deduct tax key: Used for deducting the tax amount from the displayed figure.

ASIAN VALUE CALCULATION

[万] [千] : When calculating large amounts, these buttons can help calculate the face value of each and every unit correctly, avoiding hand entry errors and saving time.

*1 During the calculations, each time when [万] or [千] key is pressed. Number "0" will become a bit smaller than normal.
In this case, other numbers (such as 1, 2, 3, 4....) can still be entered continuously, but when an operational command key (such as +, −, x, ÷ or =) is pressed, the display will restore to normal status for calculation work.

*2 If there are any decimal units in the calculation, the " 億千万 " indication will not show up in the display.

[千万単位/メモリー] : When [千万単位/メモリー] key is pressed, the " 億千万 " will show up in the display.

OVERFLOW FUNCTIONS

In the following cases, "E" will be shown on the display. The keyboard is electronically locked, and further operation is impossible.
Press [CI/C] key to clear the overflow. The overflow occurs when:

1. The result or the memory content exceeds 12 digits.
2. Dividing by "0".

SPECIFICATIONS

Power Source: Solar cell and alkaline battery (LR44 x 1)
Operating Temperature : 0ºC to 40ºC
Automatic Power-off : approx. 7 minutes
Dimension: 147mm (L) x 106mm (W) x 25mm (H)
Weight : 117 g
All specifications are subject to change without notice