

AS-120R

CHECK AND CORRECT FUNCTION

This calculator has a 120 steps replay memory capacity which is useful for checking the calculation process. Input data can be edited by correcting the figures.

▲ ▼ : Used for reviewing the process of the calculation. Press **▲ ▼** key to review the previous or next calculation step.

- The step indicator shows the number of steps of the current calculation on display.
- When reviewing the process with **▲ ▼** key, "Percent", or "Constant" calculation will be displayed as "%", or "K" indicator.
- If a calculation exceeds 120 steps, the step indicator will blink; and further calculations will not be recorded within the replay memory.

CORRECT : Used for changing calculation contents in the Replay mode.

- The **CORRECT** function can only work up to 119 steps. No correction can be made over 119 steps.
- The **CORRECT** function is operative only for complete equations finished with "=".

AUTO CHECK : Press **AUTO CHECK** to scrolls through the calculation steps from beginning to end. And press **AUTO CHECK**, **▲**, **▼** to stop the auto check operation.

Calculation Example / Contoh Perhitungan / Ví dụ

Check	ONVCA	Display
(500+300-60) x 5 = 3,700	500 + 300 = 60 x	(0.) 03 740.)
(500+300-60) x 2 = 1,480 * Constant Calculation	5 = 2 =	(05 3'700.) (07 1'480.)
	▼	(01 CHECK 500.)
	▼	(02 CHECK 300.)
	▼	(03 CHECK 60.)
	▼	(04 CHECK 5.)
	▼	(05 CHECK 3'700.)
	▼	(06 CHECK 2.)
	▼	(07 CHECK K 1'480.)
Correct "+300" to "-200" (500+300-60) x 5 = 3,700 (500+300-60) x 2 = 1,480	▼ ▼ CORRECT 200 CORRECT	(07 CHECK K 1'480.) (02 CHECK 300.) (02 CORRECT 300.) (03 CHECK 200.) (04 CHECK 60.) (05 CHECK 5.) (06 CHECK 1'200.) (07 CHECK K 480.)
(500-200-60) x 5 = 1,200	▼	
(500-200-60) x 2 = 480	▼	

© CANON ELECTRONIC BUSINESS MACHINES (H.K.) CO., LTD. 2023

E-IE-523

CUT AS SHOWN ON THE BACK TO SEE THE
CALCULATION EXAMPLE AND IMPORTANT NOTES
INSIDE THE BOX.

Printed in China

POWER SUPPLY

This calculator comes with a dual power source. The duration of alkaline battery depends entirely on individual usage.

(Note: Do not attempt to change the battery by yourself. Have a Canon Service Center change the battery for you).

- Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the contents of the memory to be lost or altered. Should this occur, press the **ONVCA** key and re-start your calculation from the beginning.

SPECIFICATION

Power Source: Solar cell and Alkaline battery (LR44 X 1)

Automatic Power-off : approx. 7 minutes

Usable Temperature : 0°C to 40°C

Dimensions: 145mm (L) x 100mm (W) x 33.5mm (H)

Weight: 108 g

(Subject to change without notice)

Calculation Example / Contoh Perhitungan / Ví dụ

Calculation	Operation	Display
MIXED 2 x 2 = 6 -7 x 9 = -63 (2+4) ÷ 3 x 8.1 = 16.2	ONVCA 2 x 2 = 6 -7 x 9 = -63 2 + 4 = 3 x 8.1 = 16.2	((0.) ((6.) ((-63.) ((16.2)
CONSTANT 2+3=5 4+3=7 1-2=-1 2-2=0 2x3=6 2x4=8 6÷3=2 9÷3=3	2 + 3 = 4 + 3 = 1 - 2 = 2 - 2 = 2 x 3 = 2 x 4 = 6 ÷ 3 = 9 ÷ 3 =	((5.) ((7.) ((-1.) ((0.) ((6.) ((8.) ((2.) ((3.)
MEMORY 3 x 4 = 12 -) 6 ÷ 0.2 = 30 -18 + 200 182	ONVCA 3 x 4 = 12 6 ÷ 0.2 = 30 -18 200 RMV/CM (Recall Memory) RMV/CM (Clear Memory)	((M 0.) ((M 12.) ((M 30.) ((M -18.) ((M 200.) ((M 182.) ((182.)
OVERFLOW 123456789x78900= 9740740652100 (ERROR)	123456789 x 78900 = C/C	((E 9.74074065210) ((9.74074065210)
6 ÷ 0 = 0 (ERROR)	6 ÷ 0 = C/C	((E 0.) ((0.)

CANON ELECTRONIC BUSINESS MACHINES (H.K.) CO., LTD.
17/F., Tower One, Ever Gain Plaza, 82-100 Container Port Road,
Kwai Chung, New Territories, Hong Kong
CANON MARKETING (MALAYSIA) SDN BHD.
No. 6-2-01, Canon Tower, UOA Business Park (Tower 6),
Jalan Pengaturcaraan U1/51A, Seksyen U1, 40150 Shah Alam,
Selangor Darul Ehsan, Malaysia